

OPERATION OF FRESH OIL POLY TROLLEY

ADDING NEW OIL TO FRYER

1. Push the Poly Trolley in front of the fryer.
2. Hold the hose by the wand over the fryer with the outlet pointing down and low.
3. Flick the switch that is located on the side of the Poly Trolley head unit and oil will commence filling the fryer.
4. Fill to your desired amount and then switch the head unit off.
5. Place the wand end back into the hole located on top of the head unit, this will keep it secure; do not let it dangle to the ground.
6. Recharge after use.

SWAPPING THE HEAD UNIT TO NEW POLY TROLLEY

1. Peel the sticker off the top of the new poly to show the opening.
2. Pull the top of the poly bag out to reveal the zip tie and undo it. All zip ties we use are reusable; do not cut the zip tie off.
3. Open the bag up and spread the excess over the top of Poly Trolley.
4. Make sure empty Poly Trolley is side by side with new fresh oil to transfer. Lift the head unit with the pipe attached out of the empty one and place it on top of the new one.
5. If there is any oil remaining in the old Poly Trolley it is recommended to use it as soon as you can, by either pulling out the bag yourself and emptying into a fryer or leaving it for one of our staff to do at your next delivery.

